

SERVICE & OPERATING MANUAL



Model S10 Non-Metallic Design Level 1

U.S. Patent #
400,210
5,996,627;
6,241,487




Table of Contents


Engineering Data and Temperature Limitations	1	Available Service and Conversion Kits	12
Explanation of Pump Nomenclature	2	Composite Repair Parts List	13
Performance Curve	3	Solenoid Shifted Valve Drawing and Parts List	14
Dimensions: S10 Non-Metallic	4	Solenoid Shifted Air Distribution Valve Option	15
Metric Dimensions: S10 Non-Metallic	5	Intermediate Assembly Drawing	16
Principle of Pump Operation	6	Intermediate Assembly Servicing	16
Installation and Start-up	6	Modular Check Ball Valve Drawing	17
Air Supply	6	Modular Check Ball Valve Servicing	17
Air Valve Lubrication	6	Diaphragm Service Drawing, Non-Overlay	18
Air Line Moisture	6	Diaphragm Service Drawing with Overlay	18
Air Inlet and Priming	6	Diaphragm Servicing, Overlay Diaphragm Servicing	19
Between Uses	6	Pumping Hazardous Liquids	20
Installation Guide	7	Converting the Pump for Piping the Exhaust Air	20
Troubleshooting	8	Exhaust Conversion Drawing	20
Warranty	8	Converted Exhaust Illustration	20
Important Safety Information	9	Pulse Output Kit Drawing, Option	21
Material Codes	10	Exhaust Port or Auxiliary Muffler Setup	21
Composite Repair Parts Drawing	12	Integral Muffler Setup	21
Overlay Option Drawing	12		

**WARREN
RUPP®**

Quality System
ISO9001 Certified

Environmental
Management System
ISO14001 Certified

IDEX
IDEX CORPORATION



CE

U.S. Patent #
5,851,109; 5,996,627;
400,210 & 6,241,487
Other U.S. Patents
Applied for

SANDPIPER
A WARREN RUPP PUMP BRAND

S10 Non-Metallic Design Level 1 Ball Valve

**Air-Powered
Double-Diaphragm Pump**

ENGINEERING, PERFORMANCE
& CONSTRUCTION DATA

INTAKE/DISCHARGE PIPE SIZE 1" ANSI Flange	CAPACITY 0 to 23 US gallons per minute (0 to 87 liters per minute)	AIR VALVE No-lube, no-stall design	SOLIDS-HANDLING Up to .15 in. (4mm)	HEADS UP TO 100 psi or 231 ft. of water (7 bar or 70 meters)	DISPLACEMENT/STROKE .026 US gallon / .098 liter
---	---	---	---	---	---

⚠ CAUTION! Operating temperature limitations are as follows:

Materials	Operating Temperatures		
	Maximum*	Minimum*	Optimum**
Santoprene® Injection molded thermoplastic elastomer with no fabric layer. Long mechanical flex life. Excellent abrasion resistance.	212°F 100°C	-10°F -23°C	50° to 212°F 10°C to 100°C
PTFE Chemically inert, virtually impervious. Very few chemicals are known to react chemically with Teflon: molten alkali metals, turbulent liquid or gaseous fluorine and a few fluoro-chemicals such as chlorine trifluoride or oxygen difluoride which readily liberate free fluorine at elevated temperatures.	212°F 100°C	-35°F -37°C	50°F to 212°F 10°C to 100°C
PVDF	200°F -93°C	-10°F -13°C	
Polypropylene			
Polyurethane	210°F 99°C	-40°F -40°C	-40°F to 210°F -40°C to 99°C
Nylon	120°F 48°C	32°F 0°C	

For specific applications, always consult "Chemical Resistance Chart" Technical Bulletin

SandPIPER® pumps are designed to be powered only by compressed air.

*Definite reduction in service life.

**Minimal reduction in service life at ends of range.

S10 Non-Metallic · Design Level 1 · Ball Valve

Type	Pump Brand	Pump Size	Check Valve Type	Design Level	Wetted Material	Diaphragm/Check Valve Options	Check Valve Seat	Non-Wetted Material Options	Porting Options	Pump Style	Pump Options	Kit Options	Shipping Weight lbs (kg)
S10B1P1PPAS000.	S	10	B	1	P	1	P	P	A	S	0	00.	19 (9)
S10B1P2PPAS000.	S	10	B	1	P	2	P	P	A	S	0	00.	19 (9)
S10B1K1KPAS000.	S	10	B	1	K	1	K	P	A	S	0	00.	23 (10)
S10B1K2KPAS000.	S	10	B	1	K	2	K	P	A	S	0	00.	23 (10)
S10B1N1NPAS000.	S	10	B	1	N	1	N	P	A	S	0	00.	20 (9)
S10B1N2NPAS000.	S	10	B	1	N	2	N	P	A	S	0	00.	20 (9)

Pump Brand

S= SandPIPER®

Pump Size

10= 1"

Check Valve Type

B= Ball

T= Tihedral

Design Level

1= Design Level 1

Wetted Material

K= PVDF

N= Nylon

P= Polypropylene

Daiphragm/Check Valve Materials

1= Santoprene/Santoprene

2= Virgin PTFE-Santoprene Backup/Virgin PTFE

7= Santoprene/Buna

8= Virgin PTFE-Santoprene Backup/Viton

Check Valve Seat

K= PVDF

N= Nylon

P= Polypropylene

Non-Wetted Material Options

P= Polypropylene

I= Polypropylene with PTFE Hardware

Porting Options

A= ANSI Flange

Pump Style

S= Standard

Pump Options

0= None

2= Mesh Muffler

Kit Options

A= ANSI Flange

N= NPT Threads

1= Dual Porting (NPT)

2= Top Dual Porting (NPT)

3= Bottom Dual Porting (NPT)


4= Dual Porting (BSPT) (tapered)

5= Top Dual Porting (BSPT) (tapered)



6= Bottom Dual Porting (BSPT) (tapered)

B= Bottom Dual Porting (tapered)

Performance Curve, S10 Non-Metallic, Design Level 1




Dimensions: S10 Non-Metallic



Dimension	A	B
Standard Pump	4 1/16"	7 9/16"
Pulse Output Kit	5 13/16"	9 5/16"
Mesh Muffler	5 3/4"	9 1/4"

Metric Dimensions: S10 Non-Metallic

Dimensions in Millimeters



PRINCIPLE OF PUMP OPERATION

This ball type check valve pump is powered by compressed air and is a 1:1 ratio design. The inner side of one diaphragm chamber is alternately pressurized while simultaneously exhausting the other inner chamber. This causes the diaphragms, which are connected by a common rod secured by plates to the centers of the diaphragms, to move in a reciprocating action. (As one diaphragm performs the discharge stroke the other diaphragm is pulled to perform the suction stroke in the opposite chamber.) Air pressure is applied over the entire inner surface of the diaphragm while liquid is discharged from the opposite side of the diaphragm. The diaphragm operates in a balanced condition during the discharge stroke which allows the pump to be operated at discharge heads over 200 feet (61 meters) of water.

For maximum diaphragm life, keep the pump as close to the liquid being pumped as possible. Positive suction head in excess of 10 feet of liquid (3.048 meters) may require a back pressure regulating device to maximize diaphragm life.

Alternate pressurizing and exhausting of the diaphragm chamber is performed by an externally mounted, pilot operated, four way spool type air distribution valve. When the spool shifts to one end of the valve body, inlet pressure is applied to one diaphragm chamber and the other diaphragm chamber exhausts. When the spool

shifts to the opposite end of the valve body, the pressure to the chambers is reversed. The air distribution valve spool is moved by an internal pilot valve which alternately pressurizes one end of the air distribution valve spool while exhausting the other end. The pilot valve is shifted at each end of the diaphragm stroke when an actuator plunger is contacted by the diaphragm plate. This actuator plunger then pushes the end of the pilot valve spool into position to activate the air distribution valve.

The chambers are connected with manifolds with a suction and discharge check valve for each chamber, maintaining flow in one direction through the pump.

INSTALLATION AND START-UP

Locate the pump as close to the product being pumped as possible. Keep the suction line length and number of fittings to a minimum. Do not reduce the suction line diameter.

For installations of rigid piping, short sections of flexible hose should be installed between the pump and the piping. The flexible hose reduces vibration and strain to the pumping system. A surge suppressor is recommended to further reduce pulsation in flow.

AIR SUPPLY

Air supply pressure cannot exceed 100 psi (7 bar). Connect the pump air inlet to an air supply of sufficient capacity and pressure required for desired performance. When the air

supply line is solid piping, use a short length of flexible hose not less than 1/2" (13mm) in diameter between the pump and the piping to reduce strain to the piping. The weight of the air supply line, regulators and filters must be supported by some means other than the air inlet cap. Failure to provide support for the piping may result in damage to the pump. A pressure regulating valve should be installed to insure air supply pressure does not exceed recommended limits.

AIR VALVE LUBRICATION

The air distribution valve and the pilot valve are designed to operate WITHOUT lubrication. This is the preferred mode of operation. There may be instances of personal preference or poor quality air supplies when lubrication of the compressed air supply is required. The pump air system will operate with properly lubricated compressed air supply. Proper lubrication requires the use of an air line lubricator (available from Warren Rupp) set to deliver one drop of SAE 10 non-detergent oil for every 20 SCFM (9.4 liters/sec.) of air the pump consumes at the point of operation. Consult the pump's published Performance Curve to determine this.

AIR LINE MOISTURE

Water in the compressed air supply can create problems such as icing or freezing of the exhaust air, causing the pump to cycle erratically or stop operating. Water in the air supply can be reduced by using a point-of-use air dryer

to supplement the user's air drying equipment. This device removes water from the compressed air supply and alleviates the icing or freezing problems.

AIR INLET AND PRIMING

To start the pump, open the air valve approximately 1/2" to 3/4" turn. After the pump primes, the air valve can be opened to increase air flow as desired. If opening the valve increases cycling rate, but does not increase the rate of flow, cavitation has occurred. The valve should be closed slightly to obtain the most efficient air flow to pump flow ratio.

BETWEEN USES

When the pump is used for materials that tend to settle out or solidify when not in motion, the pump should be flushed after each use to prevent damage. (Product remaining in the pump between uses could dry out or settle out. This could cause problems with the diaphragms and check valves at restart.) In freezing temperatures the pump must be completely drained between uses in all cases.





INSTALLATION GUIDE

Top Discharge Ball or Flap Valve Unit

Available from
Warren Rupp

- ① Surge Dampener
- ② Filter/Regulator
- ③ Lubricator



TROUBLESHOOTING

Possible Symptoms:

- Pump will not cycle.
- Pump cycles, but produces no flow.
- Pump cycles, but flow rate is unsatisfactory.
- Pump cycle seems unbalanced.
- Pump cycle seems to produce excessive vibration.

What to Check: Excessive suction lift in system.

Corrective Action: For lifts exceeding 20 feet (6 meters), filling the pumping chambers with liquid will prime the pump in most cases.

What to Check: Excessive flooded suction in system.

Corrective Action: For flooded conditions exceeding 10 feet (3 meters) of liquid, install a back pressure device.

What to Check: System head exceeds air supply pressure.

Corrective Action: Increase the inlet air pressure to the pump. Most diaphragm pumps are designed for 1:1 pressure ratio at zero flow.

What to Check: Air supply pressure or volume exceeds system head.

Corrective Action: Decrease inlet air pressure and volume to the pump as calculated on the published PERFORMANCE CURVE. Pump is cavitating the fluid by fast cycling.

What to Check: Undersized suction line.

Corrective Action: Meet or exceed pump connection recommendations shown on the DIMENSIONAL DRAWING.

What to Check: Restricted or undersized air line.

Corrective Action: Install a larger air line and connection. Refer to air inlet recommendations shown in your pump's SERVICE MANUAL.

What to Check: Check ESADS, the Externally Serviceable Air Distribution System of the pump.

Corrective Action: Disassemble and inspect the main air distribution valve, pilot valve and pilot valve actuators. Refer to the parts drawing and air valve section of the SERVICE MANUAL. Check for clogged discharge or closed valve before reassembly.

What to Check: Rigid pipe connections to pump.

Corrective Action: Install flexible connectors and a surge suppressor.

What to Check: Blocked air exhaust muffler.

Corrective Action: Remove muffler screen, clean or de-ice and reinstall. Refer to the Air Exhaust section of your pump SERVICE MANUAL.

What to Check: Pumped fluid in air exhaust muffler.

Corrective Action: Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly. Refer to the Diaphragm Replacement section of your pump SERVICE MANUAL.

What to Check: Suction side air leakage or air in product.

Corrective Action: Visually inspect all suction side gaskets and pipe connections.

What to Check: Obstructed check valve.

Corrective Action: Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket. Refer to the Check Valve section of the pump SERVICE MANUAL for disassembly instructions.

What to Check: Worn or misaligned check valve or check valve seat.

Corrective Action: Inspect check valves and seats for wear and proper seating. Replace if necessary. Refer to Check Valve section of the pump SERVICE MANUAL for disassembly instructions.

What to Check: Blocked suction line.

Corrective Action: Remove or flush obstruction. Check and clear all suction screens and strainers.

What to Check: Blocked discharge line.

Corrective Action: Check for obstruction or closed discharge line valves.

What to Check: Blocked pumping chamber.

Corrective Action: Disassemble and inspect the wetted chambers of the pump. Remove or flush any obstructions. Refer to the pump SERVICE MANUAL for disassembly instructions.

What to Check: Entrained air or vapor lock in one or both pumping chambers.

Corrective Action: Purge chambers through tapped chamber vent plugs. PURGING THE CHAMBERS OF AIR CAN BE DANGEROUS! Contact the Warren Rupp Technical Services Department before performing this procedure. A model with top-ported discharge will reduce or eliminate problems with entrained air.

If your pump continues to perform below your expectations, contact your local Warren Rupp Distributor or factory Technical Services Group for a service evaluation.

WARRANTY

Refer to the enclosed Warren Rupp Warranty Certificate.

Recycling

Many components of SandPIPER® Metallic AODD pumps are made of recyclable materials (see chart on page 9 for material specifications). We encourage pump users to recycle worn out parts and pumps whenever possible, after any hazardous pumped fluids are thoroughly flushed.

Important Safety Information



IMPORTANT

Read these safety warnings and instructions in this manual completely, before installation and start-up of the pump. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.



CAUTION

Before pump operation, inspect all gasketed fasteners for looseness caused by gasket creep. Re-torque loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



WARNING

Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. The discharge line may be pressurized and must be bled of its pressure.



WARNING

When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



WARNING

Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers or other miscellaneous equipment must be grounded.



WARNING

This pump is pressurized internally with air pressure during operation. Always make certain that all bolting is in good condition and that all of the correct bolting is reinstalled during assembly.



WARNING

In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. If pumping a product which is hazardous or toxic, the air exhaust must be piped to an appropriate area for safe disposition.



WARNING

Before doing any maintenance on the pump, be certain all pressure is completely vented from the pump, suction, discharge, piping, and all other openings and connections. Be certain the air supply is locked out or made non-operational, so that it cannot be started while work is being done on the pump. Be certain that approved eye protection and protective clothing are worn all times in the vicinity of the pump. Failure to follow these recommendations may result in serious injury or death.



WARNING

Airborne particles and loud noise hazards. Wear ear and eye protection.

Material Codes

The Last 3 Digits of Part Number

000 Assembly, sub-assembly; and some purchased items	175 Die Cast Zinc	375 Fluorinated Nitrile	610 PTFE Encapsulated Silicon
010 Cast Iron	180 Copper Alloy	378 High Density Polypropylene	611 PTFE Encapsulated Viton
012 Powered Metal	305 Carbon Steel, Black Epoxy Coated	405 Cellulose Fibre	632 Neoprene/Hytrel
015 Ductile Iron	306 Carbon Steel, Black PTFE Coated	408 Cork and Neoprene	633 Viton/PTFE
020 Ferritic Malleable Iron	307 Aluminum, Black Epoxy Coated	425 Compressed Fibre	634 EPDM/PTFE
025 Music Wire	308 Stainless Steel, Black PTFE Coated	426 Blue Gard	635 Neoprene/PTFE
080 Carbon Steel, AISI B-1112	309 Aluminum, Black PTFE Coated	440 Vegetable Fibre	637 PTFE , Viton/PTFE
100 Alloy 20	310 Kynar® Coated	465 Fibre	638 PTFE , Hytrel/PTFE
110 Alloy Type 316 Stainless Steel	330 Zinc Plated Steel	500 Delrin 500	639 Buna-N/TFE
111 Alloy Type 316 Stainless Steel (Electro Polished)	331 Chrome Plated Steel	501 Delrin 570	643 Santoprene®/EPDM
112 Alloy "C" (Hastelloy equivalent)	332 Aluminum, Electroless Nickel Plated	502 Conductive Acetal, ESD-800	644 Santoprene®/PTFE
113 Alloy Type 316 Stainless Steel (Hand Polished)	333 Carbon Steel, Electroless Nickel Plated	503 Conductive Acetal, Glass-Filled	656 Santoprene Diaphragm and Check Balls/EPDM Seats
114 303 Stainless Steel	335 Galvanized Steel	505 Acrylic Resin Plastic	
115 302/304 Stainless Steel	336 Zinc Plated Yellow Brass	506 Delrin 150	
117 440-C Stainless Steel (Martensitic)	337 Silver Plated Steel	520 Injection Molded PVDF Natural color	
120 416 Stainless Steel (Wrought Martensitic)	340 Nickel Plated	540 Nylon	
123 410 Stainless Steel (Wrought Martensitic)	342 Filled Nylon	541 Nylon	
148 Hardcoat Anodized Aluminum	353 Geolast; Color: Black	542 Nylon	
149 2024-T4 Aluminum	354 Injection Molded #203-40 Santoprene- Duro 40D +/-5; Color: RED	544 Nylon Injection Molded	
150 6061-T6 Aluminum	355 Thermal Plastic	550 Polyethylene	
151 6063-T6 Aluminum	356 Hytrel	551 Glass Filled Polypropylene	
152 2024-T4 Aluminum (2023-T351)	357 Injection Molded Polyurethane	552 Unfilled Polypropylene	
154 Almag 35 Aluminum	358 Urethane Rubber (Some Applications) (Compression Mold)	553 Unfilled Polypropylene	
155 356-T6 Aluminum	359 Urethane Rubber	555 Polyvinyl Chloride	
156 356-T6 Aluminum	360 Buna-N Rubber. Color coded: RED	556 Black Vinyl	
157 Die Cast Aluminum Alloy #380	361 Buna-N	570 Rulon II	
158 Aluminum Alloy SR-319	363 Viton (Fluorel). Color coded: YELLOW	580 Ryton	
159 Anodized Aluminum	364 E.P.D.M. Rubber. Color coded: BLUE	590 Valox	
162 Brass, Yellow, Screw Machine Stock	365 Neoprene Rubber. Color coded: GREEN	591 Nylatron G-S	
165 Cast Bronze, 85-5-5-5	366 Food Grade Nitrile	592 Nylatron NSB	
166 Bronze, SAE 660	368 Food Grade EPDM	600 PTFE (virgin material) Tetrafluorocarbon (TFE)	
170 Bronze, Bearing Type, Oil Impregnated	370 Butyl Rubber. Color coded: BROWN	601 PTFE (Bronze and moly filled)	
	371 Philthane (Tuftane)	602 Filled PTFE	
	374 Carboxylated Nitrile	603 Blue Gylon	
		604 PTFE	
		607 Envelon	
		606 PTFE	

Delrin, Viton and Hytrel are registered tradenames of E.I. DuPont.
Gylon is a registered tradename of Garlock, Inc.
Nylatron is a registered tradename of Polymer Corp.
Santoprene is a registered tradename of Monsanto Corp.
Rulon II is a registered tradename of Dixon Industries Corp.
Hastelloy-C is a registered tradename of Cabot Corp.
Ryton is a registered tradename of Phillips Chemical Co.
Valox is a registered tradename of General Electric Co.
Kynar® is a registered tradename of ATOFINA Chemicals, Inc.
Warren Rupp, SandPIPER, Portapump, Tranquillizer and SludgeMaster are registered tradenames of Warren Rupp, Inc.

Composite Repair Parts Drawing

AVAILABLE SERVICE AND CONVERSION KITS

476-219-000 AIR END KIT

Seals, O-rings, Gaskets, Bumpers, Retaining Rings, Air Valve Assembly and Pilot Valve Assembly.

476-220-000 AIR END KIT for pumps

equipped with Stroke Indicator (same components as above, except Valve Assembly with pins replaces Standard Air Valve).

476-166-354 WETTED END KIT

Santoprene Diaphragms, Nitrile Spacer Gaskets, Santoprene Check Balls and TFE Seals.

476-166-650 WETTED END KIT

uniRupp® PTFE/Santoprene Bond Diaphragm, PTFE Check Balls and PTFE Seals.

476-166-654 WETTED END KIT

Santoprene Diaphragms, TFE Overlay Diaphragm, TFE Check Balls and TFE Seals.

476-180-657 WETTED END KIT (S07T)

Santoprene Diaphragms, Buna Trihedral Valve Components, Buna Spacer Gaskets, and TFE Manifold Seals.

476-180-658 WETTED END KIT (S07T)

Santoprene Backup Diaphragms, TFE Overlay Diaphragms, Viton Trihedral Valve Components, and TFE Manifold Seals.

PULSE OUTPUT KITS

(For use with 530-031-550 encapsulated muffler)

475-198-021 DC Kit

475-198-022 DC Intrinsically Safe Kit

475-198-023 110/120VAC or 220/240VAC Kit

475-198-024 110/120VAC Intrinsically Safe Kit

475-198-025 220/240VAC Intrinsically Safe Kit

(For use with 530-024-000 muffler or piped exhaust)

475-198-026 DC Kit


475-198-027 DC Intrinsically Safe Kit

475-198-028 110/120VAC or 220/240VAC Kit

475-198-029 110/120VAC Intrinsically Safe Kit

475-198-030 220/240VAC Intrinsically Safe Kit

NOTE: For Trihedral Parts, see Modular Trihedral Check Valve page.



Composite Repair Parts List

NOTE: See Pages 14 and 16 For Full Explanation of Air Valve Options.

ITEM	PART NUMBER	DESCRIPTION	QTY	ITEM	PART NUMBER	DESCRIPTION	QTY
1	031-166-000	Air Valve Assembly (Integral Muffler)	1		312-107-542	Elbow	4
	031-166-002	Air Valve Assembly (with PTFE Coated Hardware)	1		312-107-552	Elbow	4
	031-167-000	Air Valve Assembly (with stroke Indicator Pins)	1	18	360-099-360	Gasket, Spacer	2
	031-167-002	Air Valve Assembly (with Stroke Indicator Pins and PTFE Coated Hardware)	1	19	360-100-360	Gasket, Air Inlet	1
	031-168-000	Air Valve Assembly (Optional Mufflers)	1	20	360-101-379	Gasket, Pilot Valve	1
	031-168-000	Air Valve Assembly (Stroke Indicator & Optional Mufflers)	1	21	360-102-360	Gasket, Air Valve	1
	031-176-000	Air Valve (High Temperature)	1	22	518-140-520	Manifold (ANSI)	2
	031-177-000	Air Valve (High Temperature With Mufflers)	1		518-140-542	Manifold (ANSI)	2
2	050-028-354	Ball, Check Valve	4	23	518-140-552	Manifold (ANSI)	2
	050-028-600	Ball, Check Valve	4		530-023-600	Muffler	1
3	095-091-000	Pilot Valve Assembly	1		530-024-000	Muffler	1
	095-091-558	Pilot Valve Assembly (Conductive Acetal)	1	24	544-005-115	Nut, Flanged 5/16-18	36
4	114-023-551	Bracket, Intermediate	1		544-005-308	Nut, Flanged 5/16-18	36
5	115-142-115	Bracket, Mounting	2	25	560-001-360	O-ring	2
6	132-034-360	Bumper, Diaphragm	2	26	612-091-520	Plate, Outer Diaphragm	2
7	135-036-506	Bushing, Plunger	2		612-091-542	Plate, Outer Diaphragm	2
8	165-110-551	Cap, Air Inlet	1	27	612-091-552	Plate, Outer Diaphragm	2
9	171-062-115	Capscrew, Flanged 5/16-18 x 1.00	12	28	612-177-150	Plate, Inner Diaphragm	2
	171-062-308	Capscrew, Flanged 5/16-18 x 1.00	12	29	620-019-115	Plunger, Actuator	2
10	171-063-115	Capscrew, Flanged 5/16-18 x 1.25	24		670-050-520	Retainer, Ball	4
	171-063-308	Capscrew, Flanged 5/16-18 x 1.25	24		670-050-542	Retainer, Ball	4
11	171-064-115	Capscrew, Flanged 5/16-18 x 1.50	12	30	670-050-552	Retainer, Ball	4
	171-064-308	Capscrew, Flanged 5/16-18 x 1.50	12	31	675-042-115	Ring, Retaining	2
12	171-066-115	Capscrew, Flanged 1/4-20 x 1.25	8	32	685-056-120	Rod, Diaphragm	1
	171-066-308	Capscrew, Flanged 1/4-20 x 1.25	8	33	720-012-375	Seal, Diaphragm Rod	2
14	196-162-520	Chamber, Outer	2	34	720-046-600	Seal, Manifold	4
	196-162-542	Chamber, Outer	2	35	720-051-600	Seal, Check Valve Retainer	8
	196-162-552	Chamber, Outer	2		722-081-520	Seat, Check Valve	4
15	286-095-354	Diaphragm	2		722-081-542	Seat, Check Valve	4
	286-095-650	Diaphragm, uniRupp	2		722-081-552	Seat, Check Valve	4
16	286-096-600	Diaphragm, Overlay	2	NOT SHOWN:			
17	312-107-520	Elbow	4		535-069-000	Nameplate	


Solenoid Shifted Air Valve Drawing

Solenoid Shifted Air Valve Parts List

Item	Part Number	Description	Qty
4	114-023-551	Bracket, Intermediate	1
19	360-100-379	Gasket, Air Inlet	1
47	893-093-000	Solenoid Valve, NEMA4	1
48	219-001-000	Solenoid Coil, 24VDC	1
	219-004-000	Solenoid Coil, 24VAC/12VDC	1
	219-002-000	Solenoid Coil, 120VAC	1
	219-003-000	Solenoid Coil, 240VAC	1
49	241-001-000	Connector, Conduit	1
50	171-065-115	Capscrew, Flanged 1/4-20 x 1.00	4
52	618-050-150	Plug (Replaces item 7)	2

For Explosion Proof Solenoid Valve:

47	893-094-001	Solenoid Valve, NEMA 7/9, 24VDC	1
	893-094-002	Solenoid Valve, NEMA 7/9, 24VAC/ 12VDC	1
	893-094-003	Solenoid Valve, NEMA 7/9, 120VAC	1
	893-094-004	Solenoid Valve, NEMA 7/9, 240VAC	1



SOLENOID SHIFTED AIR DISTRIBUTION VALVE OPTION


Warren Rupp's solenoid shifted, air distribution valve option utilizes electrical signals to precisely control your SandPIPER's speed. The solenoid coil is connected to a customer - supplied control. Compressed air provides the pumping power, while electrical signals control pump speed (pumping rate).

OPERATION


The Solenoid Shifted SandPIPER has a solenoid operated, air distribution valve in place of the standard SandPIPER's pilot operated, air distribution valve. Where a pilot valve is normally utilized to cycle the pump's air distribution valve, an electric solenoid is utilized. As the solenoid is powered, one of the pump's air chambers is pressurized while the other chamber is exhausted. When electric power is turned off, the solenoid shifts and the pressurized chamber is exhausted while the other chamber is pressurized. By alternately applying and removing power to the solenoid, the pump cycles much like a standard SandPIPER pump, with one exception. This option provides a way to precisely control and monitor pump speed.

BEFORE INSTALLATION

Before wiring the solenoid, make certain it is compatible with your system voltage.



Intermediate Drawing



INTERMEDIATE ASSEMBLY REPAIR PARTS LIST

Item	Part Number	Description	Qty
4	114-023-551	Bracket, Intermediate	1
7	135-036-506	Bushing, Plunger	2
25	560-001-360	O-Ring	2
28	620-019-115	Plunger, Actuator	2
30	675-042-115	Ring, Retaining*	2

***NOTE:** It is recommended that when plunger components are serviced, new retaining rings be installed.

Intermediate Servicing

ACTUATOR PLUNGER SERVICING

To service the actuator plunger first shut off the compressed air supply, bleed the pressure from the pump, and disconnect the air supply line from the pump.

Step #1: See PUMP ASSEMBLY DRAWING.

Using a 3/8" wrench or socket, remove the four capscrews (items 12). Remove the air inlet cap (item 8) and air inlet gasket (item 20). The pilot valve assembly (item 3) can now be removed.

Step #2: Servicing the actuator plungers.

See PUMP ASSEMBLY DRAWING.

The actuator plungers (items 28) can be reached through the stem cavity of the pilot valve in the intermediate bracket (item 4). To service bushings, o-rings and retaining rings, see Intermediate Drawing.

Remove the plungers (items 28) from the bushings (item 7) in each end of the intermediate cavity. Inspect for wear or damage. Replace plunger as needed. Apply a light coating of grease to each o-ring and re-install the plungers in to the bushings. Push the plungers in as far as they will go.

Step #3: Re-install the pilot valve assembly into the intermediate assembly.

Be careful to align the ends of the stem between the plungers when inserting the stem of the pilot valve into the cavity of the intermediate.

Re-install the gasket (item 20), air inlet cap (item 8) and capscrews (items 12).


Connect the air supply to the pump. The pump is now ready for operation.

PLUNGER BUSHING, O-RING, AND RETAINING RING SERVICING

To service the plunger bushing components first remove the two retaining rings (items 30) using a small flat screwdriver. ***Note:** It is recommended that new retaining rings be installed.

Next remove the two plunger bushings (items 7). Inspect the bushings for wear or scratches. Replace the bushings as necessary.


Inspect the two o-rings (25) for cuts and/or wear.



! IMPORTANT

Read these instructions completely, before installation and start-up. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.

Modular Check Ball Valve Drawing



MODULAR CHECK BALL VALVE SERVICING

Before servicing the check valves, first shut off the suction line and then the discharge line to the pump. Next, shut off the compressed air supply, bleed air pressure from the pump, and disconnect the air supply line from the pump. Drain any remaining fluid from the pump. The pump can now be removed for service.

To access the modular check valve, remove the elbows (items 17 from pump composite repair parts drawing). Use a 1/2" wrench or socket to remove the fasteners. Once the elbows are removed, the modular check valves can be seen in the cavities of the outer chamber (items 14).

Next remove the check valve seal (item 34). Inspect the seal for cuts or pinched areas. Replace seal as needed.

Disassemble the component parts of each modular check valve. Inspect the check valve retainer (item 29) for cuts, abrasive wear, or embedded materials. Replace as needed.


Inspect the check balls (items 2) for wear, abrasion, or cuts on the spherical surface. The check valve seats (items 35) should be inspected for cuts, abrasive wear, or embedded material on the surfaces of both the external and internal chambers. The spherical surface of the check balls must seat flush to the surface of the inner chamfer on the check valve seats for the pump to operate to peak efficiency. Replace any worn or damaged parts as necessary.

Remove the check valve seal (item 34). Inspect the seal for cuts or pinched areas. Replace seal as needed.

RE-ASSEMBLE THE MODULAR CHECK VALVES.

Place a check valve seal (item 34) into the cavity of the outer chamber (item 14). Make sure the chamfer side of the seal faces out. Insert the modular check valve into the outer chamber with the retainer facing up. Install a check valve seal (item 34). Make sure the chamfer side of the seals face the check valve seat or retainer.

The pump can now be reassembled, reconnected and returned to operation.







! IMPORTANT

Read these instructions completely, before installation and start-up. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.


Diaphragm Service Drawing

Diaphragm Service Drawing, with Overlay


Diaphragm Service Drawing with uniRupp®



Diaphragm Orientation
Install diaphragm and spacer
as shown above.



Diaphragm Orientation
Install diaphragm and overlay
as shown above.



Diaphragm Orientation
Install diaphragm (286-095-650 only)
as shown above.

DIAPHRAGM SERVICING

To service the diaphragms first shut off the suction, then shut off the discharge lines to the pump. Shut off the compressed air supply, bleed the pressure from the pump, and disconnect the air supply line from the pump. Drain any remaining liquid from the pump.

Step #1: See the pump composite repair parts drawing, and the diaphragm servicing illustration.

Using a 1/2" wrench or socket, remove the 16 capscrews (items 9 & 10), and nuts that fasten the elbows (items 17) to the outer chambers (items 14). Remove the elbows with the manifolds and spacers attached.

Step #2: Removing the outer chambers.

Using a 1/2" wrench or socket, remove the 16 capscrews (items 9 & 11), and nuts that fasten the outer chambers, diaphragms, and intermediate bracket (items 4) together.

Step #3: Removing the diaphragm assemblies.

Use a 3/4" (19mm) wrench or six pointed socket to remove the diaphragm assemblies (outer plate, diaphragm, and inner plate) from the diaphragm rod (item 31) by turning counterclockwise.

Insert a 6-32 set screw into the smaller tapped hole in the inner diaphragm plate (item 27). Insert the protruding stud and the 6-32 fastener loosely into a vise. Use a 3/4" wrench or socket to remove the outer diaphragm

plate (item 26) by turning counterclockwise. Inspect the diaphragm (item 15) for cuts, punctures, abrasive wear or chemical attack. Replace the diaphragms if necessary.

Step #4: Installing the diaphragms.

Push the threaded stud of the outer diaphragm plate through the center hole of the diaphragm. Thread the inner plate clockwise onto the stud. Use a torque wrench to tighten the diaphragm assembly together to 90 in Lbs. (10.17 Newton meters) 120 in lbs. Santoprene (13.56 Newton meters). Allow a minimum of 15 minutes to elapse after torquing, then re-torque the assembly to compensate for stress relaxation in the clamped assembly.

Step #5: Installing the diaphragm assemblies to the pump.

Make sure the bumper (item 6) is installed over the diaphragm rod.

Thread the stud of the one diaphragm assembly clockwise into the tapped hole at the end of the diaphragm rod (item 31) until the inner diaphragm plate is flush to the end of the rod. Insert rod into pump.

Align the bolt holes in the diaphragm with the bolt pattern in the inner chamber (item 4). Make sure the molded directional arrows on the diaphragm point vertically.

Fasten the outer chamber (item 14) to the pump, using the capscrews (items 9 & 11), hex nuts and flat washers.

On the opposite side of the pump, pull the diaphragm rod out as far as

possible. Make sure the bumper (item 6) is installed over the diaphragm rod.

Thread the stud of the remaining diaphragm assembly clockwise into the tapped hole at the end of the diaphragm rod (item 31) as far as possible and still allow for alignment of the bolt holes in the diaphragm with the bolt pattern in the inner chamber. The molded directional arrows on the diaphragm must point vertically.

Fasten the remaining outer chamber (item 14) to the pump, using the capscrews (items 9 & 11) and nuts.

Step #6: Re-install the elbow/spacer/manifold assemblies to the pump, using the capscrews (items 9 & 10) and nuts.

The pump is now ready to be re-installed, connected and returned to operation.

OVERLAY DIAPHRAGM SERVICING


The PTFE overlay diaphragm (item 16) is designed to fit snugly over the exterior of the standard TPE diaphragm (item 15).

The molded directional arrows on the overlay diaphragm must point vertically.

Follow the same procedures described for the standard diaphragm for removal and installation.

uniRupp® DIAPHRAGM SERVICING

Follow the same procedures described for the standard diaphragm for removal and installation. **Note:** The uniRupp diaphragm is installed in the direction as shown in the lower right illustration above.



! IMPORTANT

Read these instructions completely, before installation and start-up. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.

PUMPING HAZARDOUS LIQUIDS

When a diaphragm fails, the pumped liquid or fumes enter the air end of the pump. Fumes are exhausted into the surrounding environment. When pumping hazardous or toxic materials, the exhaust air must be piped to an appropriate area for safe disposal. See illustration #1 at right.

This pump can be submerged if the pump materials of construction are compatible with the liquid being pumped. The air exhaust must be piped above the liquid level. See illustration #2 at right. Piping used for the air exhaust must not be smaller than 1/2" (1.27 cm) diameter. Reducing the pipe size will restrict air flow and reduce pump performance. When the pumped product source is at a higher level than the pump (flooded suction condition), pipe the exhaust higher than the product source to prevent siphoning spills. See illustration #3 at right.

CONVERTING THE PUMP FOR PIPING THE EXHAUST AIR

The following steps are necessary to convert the pump to pipe the exhaust air away from the pump.

Use a Phillips screwdriver to remove the four self-tapping screws (item 1-H).

Remove the muffler cap and muffler (items 1-G and 1-F). The 3/8" NPT molded threads in the air distribution valve body (item 1-A).


Piping or hose may now be installed.

IMPORTANT INSTALLATION NOTE:


The manufacturer recommends installing a flexible hose or connection between the pump and any rigid plumbing. This reduces stresses on the molded plastic threads of the air exhaust port. Failure to do so may result in damage to the air distribution valve body.

Any piping or hose connected to the pump's air exhaust port must be physically supported. Failure to support these connections could also result in damage to the air distribution valve body.

Exhaust Conversion Drawing



CONVERTED EXHAUST ILLUSTRATION



Pulse Output Kit Drawing


PULSE OUTPUT KIT OPTION

This pump can be fitted with a Pulse Output Kit. This converts the mechanical strokes of the pump to an electrical signal which interfaces with the RuppTech™ Stroke Counter/ Batch Controller or user control devices such as a PLC.

The Pulse Output Kits mount directly onto the Muffler Cap on the Air Distribution Valve Assembly or onto the Air Distribution Valve Assembly when the threaded exhaust port or an auxiliary muffler is being used.

See the individual kits listed on the Pump Repair Parts List for further information.

Exhaust Port or Auxiliary Muffler Setup



Integral Muffler Setup

