

OPERATION AND SERVICE MANUAL for



Diaphragm Sensed Pressure Reducing Regulators

General

Tescom's diaphragm sensed pressure reducing regulators are specifically engineered for applications requiring dependable pressure regulation. These regulators are especially appropriate for installations where high system pressures (up to 6000 psi) must be reduced to levels suitable for actuating low pressure (28 vac to 500 psi) instruments and related equipment.

Pressure Activation Methods

Tescom uses three basic types of activation methods. The activation method provides the means by which the operator can set the force that determines the outlet pressure of a regulator.

Control Knob: Delivery pressure is increased by turning the control knob. The control knob applies a load through a spring to the diaphragm.

Dome Load: Delivery pressure is increased by applying pressurized gas or liquid to the dome of a regulator at a pressure equal to the outlet pressure desired. This dome pressure is normally provided by a second regulator called the pilot regulator.

Combination Spring and Dome: Delivery pressure is increased by applying a spring force as well as the introduction of pressurized gas or liquid.

Operation (Control Knob Adjustment)

Controlled outlet pressure settings are obtained using Tescom pressure reducing regulators by adjusting the control knob. Rotating the knob clockwise raises the outlet pressure while a counterclockwise rotation coupled with venting of the downstream side of the regulator plumbing lowers the outlet pressure. Final adjustments should be made in the direction of increasing pressure to obtain the most accurate set point.

Tescom regulators will operate with any liquid or gaseous media compatible with the wetted materials. Some series/modifications come with an internal filter designed to stop random contamination resulting from the installation of the regulator. An auxiliary upstream filter is recommended for use in all but the cleanest media. Gaseous media should be free of excessive moisture to prevent icing of the regulator at high flow rates.



WARNING A REGULATOR IS NOT INTENDED TO BE USED AS A SHUTOFF DEVICE. WHEN THE REGULATOR IS NOT IN USE THE INLET SUPPLY SHOULD BE TURNED OFF. AS A SAFETY PRECAUTION, A PRESSURE RELIEF DEVICE SHOULD BE INSTALLED DOWNSTREAM OF THE REGULATOR.

Maintenance

The following procedures are provided to enable the customer to perform all normal maintenance and repair operations. These operations are more easily performed with the regulator removed from the line. However, in some cases repair may be accomplished without removal of the regulator body as long as the supply has been shut off and the inlet and outlet pressures have been vented.

The following steps outline the disassembly of pressure reducing regulators for maintenance and repair (up-to-date assembly drawings and bills of material are available from factory):

1. Clamp the regulator in a vise by the flats on the bottom and/or side of the regulator body.
2. Turn control knob and/or spring adjustment mechanism counterclockwise to insure removal of all spring force on the diaphragm.

Maintenance (continued)

NOTE: (Dome loaded regulators) All pressurized gas or liquid must be vented from dome before disassembly.

3. Remove upper portion of regulator (bonnet and/or dome). Some models require the mounting bracket to be removed first.

NOTE: Upper portion of regulator may also include spring button, load spring back-up plate, and diaphragm, etc. Review correct drawing to ensure that all parts have been disassembled.

NOTE: (Two-Stage Regulator) Tescom Model Series 44-3400 is a two-stage regulator that has portions on both ends of the regulator body that must be removed. It is Tescom's recommendation that two-stage regulators be returned to the factory for repair.

4. The valve parts can now be removed from the regulator body by turning the seat retainer and/or back cap counterclockwise until it is free of the regulator body.

NOTE: If necessary, valve seat may be removed from the seat retainer using a sharp instrument.

CAUTION: When removing valve parts from a regulator that has a back cap, care must be taken to insure the main valve stem remains vertical. If the main valve stem is not removed correctly parts may remain in the regulator.

5. To disassemble main valve assembly and/or valve, clamp valve in smoothed jaw vice or hold with pliers. Clamping should be done on flats.

CAUTION: Care must be used to not damage valve.



WARNING

SEVERAL OF TESCOM'S REGULATORS ARE SUPPLIED WITH INTERNAL FILTERS. THEY WILL BE LOCATED EITHER IN THE INLET PORT OR IN THE MAIN VALVE AREA OF THE REGULATOR. IN EACH CASE, THEY SHOULD BE REMOVED AND REPLACED BEFORE REASSEMBLY.

Reassembly

The regulator is reassembled in the reverse order of disassembly, observing the following precautions. Please reference the Bill of Material and assembly drawing for the correct location of replacement parts and correct torque specifications.

1. Inspect all parts and replace those worn or damaged with Tescom replacement parts.
2. All parts should be cleaned to the cleanliness level required for safe operation with the media and system they will be used in. All parts in the flow stream must be free of particles which could prevent proper seating of the main valve.
3. Apply a thin uniform coating of fluorocarbon grease to any or all of the following parts: indentation of spring button, threaded portion of adjusting screw, entire threaded area of the bonnet, all O-rings, all threaded parts internal to regulator.



DO NOT APPLY ANY TYPE OF GREASE TO THREADED INTERNAL PARTS OF REGULATORS THAT COME STANDARD WITH METAL TO METAL DIAPHRAGM SEALS. THESE MODELS INCLUDE THE FOLLOWING REGULATOR SERIES: 44-2200, 44-2300, 44-2600, 44-2800, 44-3200, 44-3400, 44-4600 AND 44-4800 SERIES.

NOTE: Do NOT apply any type of grease to the **inlet** or **outlet** connections.

4. Valve seat must be installed with the chamfered side towards the main valve.
5. Standard Regulator with Control Knob - The body and bonnet are best joined by holding the bonnet assembly open end up and dropping all required items into place one at a time. The last item to be placed in the bonnet will be the diaphragm. It can be centered on the seating surface of the bonnet before the body assembly is inverted and screwed into the bonnet firmly—hand tight. Regulator should then be placed in vise and bonnet retorqued to correct specifications. See print.

Reassembly (continued)

6. Dome/Combination Spring and Dome Loaded Regulators are more easily reassembled by holding regulator firmly in vise and reinstalling dome.
7. Self-Venting Regulator - If your regulator has an adjustable relief valve mechanism, it is set on final assembly at the factory and usually will not require further adjustment. If adjustment becomes necessary, use the following procedure after regulator has been installed:
Step 1. Remove hole plug in control knob.
Step 2. Using control knob, apply 10 to 15 psi on downstream side.
Step 3. Turn CW vent adjusting screw (located under hole plug) until media can be heard escaping through relief valve.

Reassembly (continued)

- Step 4. Turn screw CCW until media flow stops, plus 1/2 turn. Replace hole plug.
8. Reinstalling wire mesh inlet filter: Insert filter into primary inlet port. It then must be expanded to fit correctly. This can be accomplished by inserting a metal tool the same size as the port and then lightly tapping it with a hammer.



WARNING AFTER REGULATOR HAS BEEN REASSEMBLED, IT SHOULD BE CONNECTED TO A PRESSURE SOURCE WITH MEDIA COMPATIBLE WITH THE USE OF THE REGULATOR AND PRESSURIZED TO CHECK FOR INTERNAL AND EXTERNAL LEAKAGE AND OPERATING CHARACTERISTICS.

PRODUCT WARRANTY

Tescom Corporation ("Tescom") warrants to the initial purchaser ("Initial Purchaser", as defined below) of products manufactured and sold by its Industrial Controls Division ("ICD") and Electronic Controls Division ("ECD") that such products are free from defects in materials and workmanship under normal use and service for a period of 365 days from the date of delivery of the products ("Warranty Period"). This warranty applies only to the Initial Purchaser, that is someone who purchases products for initial use directly from Tescom, its affiliates or authorized distributors or representatives. This warranty is not transferable to subsequent purchasers or users of the products.

During the Warranty Period, Tescom will, in its sole discretion, repair or replace, free of charge at its factory in Minnesota, any product or part thereof that is found by Tescom, after reasonable notification by the Initial Purchaser, to have been defective in materials or workmanship. The Initial Purchaser must pay all shipping costs for warranty service and is responsible for risk of loss or damage of products during shipment. Tescom does not warrant, and will not pay for, any repairs or replacement made during the Warranty Period by anyone other than personnel authorized by Tescom, ICD or ECD to make such repairs or replacement.

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES. TESCOM, ICD AND ECD MAKE NO OTHER EXPRESS OR IMPLIED WARRANTY, AND IN PARTICULAR AND WITHOUT LIMITATION MAKE NO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE. The Initial Purchaser's only remedy under this warranty is repair or replacement of the products during the Warranty Period. This warranty does not apply to any product which has been damaged by accident, abuse, misuse, modification or lack of proper maintenance. NEITHER TESCOM, ICD NOR ECD WILL BE LIABLE FOR ANY CONSEQUENTIAL, SPECIAL, INCIDENTAL OR INDIRECT DAMAGES, INCLUDING WITHOUT LIMITATION, LOST PROFITS.

TESCOM
CORPORATION

INDUSTRIAL CONTROLS DIVISION • ELECTRONIC CONTROLS DIVISION
12616 Industrial Boulevard • Elk River, MN 55330

1-800-447-1250 • (763) 241-3238 • Fax: (763) 241-3224

e-mail: icd@tescom.com • www.tescom.com